- 4. Plug the DC jack of the scarf to the DC socket of the battery case.
- 5. Slide the On/Off switch on the battery case to "ON" position to turn the unit
- 6. LED on the battery case will light up to denote that the unit is in operation.
- 7. Hold the scarf to you neck to enjoy warmth of the heated scarf.
- 8. To turn off the unit, slide the On/Off switch to "OFF" position. Battery case LED will go off to denote end of operation.
- 9. When the battery is completely drained, battery case LED will go off and operation will end.

Note: Alkaline battery is recommended for longer operation.

B. Operate with external USB-DC adaptor

- 1. Plug the DC jack of the scarf to the DC socket of the USB-DC adaptor.
- 2. Plug the USB (type-A) socket to any USB power source (e.g. power bank, 5V USB power outlet, computer....) to turn on the unit.
- 3. To end, first unplug the USB socket from power source and then unplug the DC jack from the USB-DC adaptor.

INSTRUCTIONS FOR USING BATTERIES

- Always purchase the correct size and grade of battery most suited for the intended use.
- Replace all batteries at the same time.
- Do not mix old and new batteries. Do not mix alkaline.standard (carbon-zinc). or rechargeable (nickel cadmium) batteries.
- Clean the battery contacts and also those of the device prior to battery installation.

- Ensure the batteries are installed correctly with regard to polarity (+ and -).
- Remove batteries from battery case if the battery is no longer functional or if unit is not be used for an extended period of time.
- Remove used batteries promptly.

DISPOSAL OF BATTERIES

When replacing the batteries, make sure you dispose of the old batteries in accordance with applicable regulations. They should be disposed of in a location specifically designated for that purpose so they can be recycled safely and without posing any risk for the environment. Do not burn or bury them.

RECOMMENDED USAGE TIMES

As individuals' metabolisms vary, so do their responses to heat. You will soon adjust the time to suit your particular needs and personal comfort.

DISCONTINUE USE OF PRODUCT IF OVERHEATING, PAIN OR SWELLING OCCURS.

TIMER FEATURE

The heated feature will automatically shut-off after approximately 20 minutes with dry cell battery operation use only. By USB charge, there is no timer shut off feature.

GET TO KNOW YOUR HEATED SCARF



3 hours of portable heat for dry cell battery operation, total run time for USB version will be depend on the capacity of power bank used

ONE YEAR LIMITED WARRANTY

Conair will (at our option) repair or replace your appliance free of charge for 12 months from the date of purchase if the appliance is defective in workmanship or materials. To obtain service under this warranty, return the defective product to the service centre listed below, together with your purchase receipt. In the absence of a purchase receipt, the warranty period shall be 12 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN **DURATION TO THE 12 MONTH DURATION OF THIS WARRANTY.**

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER.

This warranty gives you specific legal rights, and you may also have other rights which vary from province to province. **CONAIR CONSUMER PRODUCTS ULC**

SERVICE CENTRE:

Conair Consumer Products LLC 100 Conair Parkway. Woodbridge, ON L4H 0L2

HS01C

For more information on any Conair Products call: 1-855-926-6247 Visit our Web site: www.conaircanada.ca Consumer Call Centre E-mail: Consumer Canada@Conair.com









HAVE A QUESTION?

Please do not return this product to the retailer.

CALL US FIRST!

Our customers service and product experts are ready to answer **ALL** your questions.

Please call our TOLL-FREE customer service number at :

1-855-926-6247 Or visit us online at www.conaircanada.ca

Model HS01C Instruction Booklet

For your safety and continued enjoyment of this products, always read the instruction book carefully before using.

IMPORTANT SAFETY INSTRUCTIONS DO NOT DESTROY

DANGER— TO REDUCE THE RISK OF BURNS, ELECTRIC SHOCK AND FIRE, THIS PRODUCT MUST BE USED IN ACCORDANCE WITH THE FOLLOWING INSTRUCTIONS.

- 1. READ ALL INSTRUCTIONS BEFORE USING.
- DO NOT USE WHILE SLEEPING OR DROWSY. DO NOT USE ON AN INFANT OR CHILDREN.
- 3. THIS HEATED SCARF IS NOT TO BE USED ON OR BY AN INVALID, A PARALYZED PERSON, A SLEEPING OR UNCONSCIOUS PERSON, A PERSON WITH DIABETES, OR A PERSON WITH POOR BLOOD CIRCULATION. DO NOT USE ON AREAS OF SENSITIVE SKIN.
- 4. BURNS CAN OCCUR REGARDLESS OF CONTROL SETTING. CHECK SKIN UNDER HEATED SCARF FREQUENTLY TO AVOID BURNING AND

- BLISTERING.
- 5. DO NOT USE IN OXYGEN ENRICHED ENVIRONMENT OR NEAR EQUIPMENT WHICH STORES OR EMITS OXYGEN.
- 6. DO NOT USE PINS OR OTHER METALLIC MEANS TO FASTEN THIS SCARF IN PLACE.
- 7. THIS HEATED SCARF IS INTENDED TO BE CORRECTLY USED AROUND THE NECK USE ONLY FOR ITS INTENDED USE AS DESCRIBED
- 8. DO NOT SIT ON OR AGAINST OR CRUSH HEATED SCARF
- 9. NEVER PULL THIS HEATED SCARF BY THE
 BATTERY PACK AND DO NOT USE THE BATTERY
 PACK AS A HANDLE.
- 10. KEEP THE SCARF AWAY FROM HEATED SURFACES.
- 11. NEVER DROP OR INSERT ANY OBJECT INTO THE SCARF'S BATTERY POCKET.
- 12. DO NOT USE THIS HEATED SCARF WITH LINIMENT, SALVE, OR OINTMENT PREPARATIONS THAT CONTAIN HEAT PRODUCING INGREDIENTS.

- SKIN BURNS COULD RESULT.
- 13. NEVER OPERATE THIS HEATED SCARF IF
 IT IS DAMAGED. IF IT IS NOT WORKING
 PROPERLY, RETURN THE HEATED SCARF
 TO AN AUTHORIZED SERVICE CENTER FOR
 EXAMINATION AND REPAIR.
- 14. DO NOT TAMPER WITH THIS HEATED SCARF IN ANY WAY. THERE ARE NO USER SERVICEABLE PARTS. IF FOR ANY REASON THIS SCARF DOES NOT FUNCTION SATISFACTORILY, RETURN TO AUTHORIZED SERVICE CENTER AT ADDRESS GIVEN.
- 15. THIS HEATED SCARF IS NOT A TOY. IF UNIT IS DAMAGED OR OPENED, OR LEAKING IS FOUND, DISCARD IMMEDIATELY OUT OF REACH OF CHILDREN.
- 16. CAN ICES-3(B)
- 17. SAVE THESE INSTRUCTIONS

CAUTIONS

- This heated scarf should not be used in the following cases: diabetes, tuberculosis, benign and malignant tumors, hemorrhages, inflammations of the skin, phlebitis andthrombosis, open and fresh wounds, bruises, broken skin or varicose veins, undetermined calf pain, or joint pain, or by persons with impaired sensitivity to heat.
- Consult your physician should you have any questions regarding use of this heated scarf.
- Seek medical advice immediately if a battery has been swallowed.
- If you are pregnant, consult your physician before using.
- Do not use on any unexplained pain or swollen muscles, or following a serious muscular injury, before consulting your physician.
- Keep away from children. This unit is not a toy. Children should not use it or play with it.
- Never use while sleeping or drowsy.

MAINTENANCE INSTRUCTIONS

- Store in a secure place away from excessive heat or sharp objects. If you will not be using the heating feature for more than a few days, please remove batteries.
- If the cord or heated scarf is damaged or does not operate properly, return it to an authorized service center. A Conair authorized service centre should perform any required servicing.
- Never allow the power supply cord to be excessively pulled or twisted. Inspect
 the cord frequently for damage. Stop use immediately if damage is visible, or
 unit stops, or operates intermittently.

4. WASHING INSTRUCTIONS

 NEVER dry-clean or use bleach. Do not tumble dry. Only the textile portion is cleaned, battery pack/USB cable not included.

Washing this item by hand will result in a much longer product-life than using

- HAND-WASHING
- a machine. Wash the textile by hand in lukewarm (105°F) water, using a small amount of mild laundry detergent. Soak for 5 minutes, then gently work the textile up and down for more than 5 minutes. NEVER rub or scrub the textile. Rinse thoroughly in cool water until all traces of detergent are gone. Squeeze excess water out by hand, NEVER twist. DO NOT use a wringer.
- MACHINE WASHING INSTRUCTIONS
 Wash as follows in automatic washer using delicate cycle and normal spin
 speed: Fill washer with water. Add minimum amount of all-purpose detergent,
 agitate to dissolve. Add scarf and soak five minutes. Agitate two minutes.
 Spin. Fill for cool rinse, agitate one minute then spin. A total of 5 machine
 washes are allowed.
- DRYING INSTRUCTIONS

To line dry, simply drape the item over two parallel clotheslines or a shower rod. DO NOT reconnect the item until it is completely dry. DO NOT use clothespins that can pinch wires. DO NOT iron your scarf.

TO OPERATE

A. Operate with battery case

- Slide open the battery cover
- Insert 3 x AA batteries (not included) into the battery compartment. Please observe the polarity indication engraved on the bottom of the battery compartment.
- 3. Insert the battery door back to the battery case and slide to close it.